

Stud pistol



Studpistol 980-Hp8



Cylinder house 980-006
1.




Control valve 980-015
2.



Trigger 980-014
3.



Front cap 980-005
4.



Piston 980-011
5.



Shock bar 980-009
6.



P-sats 980-Hpp
7.



O-ring cylinder house 980-004
8.



Stud nose hard metal 910-004
9.



Stud nose 910-001
10.



Envelope 980-008a+b
11.



Spreadfinger 890-060L
12.



O-ring 980-002
13.



Pistol head 980-013
14.



Lock ring 980-003
15.